

Customer ProSel

MS910-Programming

****Programming must be done while Bluetooth is OFF****

1.) Scan Disconnect –pg5 


3.) Scan “Reset” – pg13 


4.) Scan “Default” – pg13 

5.) 2.)Scan HID – pg5 

6.) Scan “MSI” – pg19 
.L001\$
Enable

7.) Scan “Zero Expansion On” – pg33 
.H053\$
Zero Expansion On

8.) Scan “Check Digit No Send” – pg31 
.L003\$
Check Digit No Send

9.) Scan “Space” in the Quick Guide book – pg 21 
.D015\$