

MS912+ Programming

****Programming must be done while Bluetooth is OFF****


1.) Scan Disconnect –pg5



3.) Scan “Reset” – pg13



4.) Scan “Default” – pg13



5.) 2.)Scan HID – pg5



.L001\$

6.) Scan “MSI” – pg19



Enable

7.) Scan “NONE” – pg 21



8.) Scan the bottom 3 in Order (Postamble, >, Postamble)

Postamble(16)



. A 0 1 3 \$



> (%I)

Postamble(16)



. A 0 1 3 \$

.H053\$



1.) Scan “Zero Expansion On” – pg33

Zero Expansion On

.L003\$



2.) Scan “Check Digit No Send” – pg31

Check Digit No Send

3.) Touch Keyboard

